

# Signature<sup>®</sup> Sauna Modes


## RESERVATION MODE

Your Signature sauna has a mode that can be activated to schedule sessions in advance.

### To Activate Reservation Mode

- Turn off sauna.
- Press the timer up and timer down arrows simultaneously.
- A digit will appear on the timer section of the screen to indicate the number of hours before the sauna turns on.
- When the timer counts down to "0," the sauna will turn on for a 60-minute session and will be set to 150 degrees.

To cancel a reservation, press the timer up and timer down arrows simultaneously until the time display turns off. At this point you can turn the sauna on normally.



# Signature<sup>®</sup> Sauna Modes

## 4-HOUR TIMER MODE

Your Signature sauna has a mode that can be activated to have extended sessions, up to four hours.

### To Activate 4-Hour Timer Mode

- With the sauna powered off, press and hold the power button until the timer display reads “4h” (~15 seconds).
- The unit will now be in “4-Hour Timer” mode and will stay in that mode until those steps are repeated.

To cancel “4-Hour Timer” mode, with the unit off, press and hold the power button until the display turns on.

